



# **OurWeather V2 and WeatherPlus Advanced Usage Manual**

November 2019

Revisions	3
Using the REST Interface built into OurWeather	3
Testing the REST Interface	3
REST Variables	3
Structure of the FullDataString Return Value	10
REST Commands	11
How to Program Your OurWeather	16
Installation of the IDE	17
Download the WeatherPlus Software for OurWeather	17
To Set the WeatherPlus Board into Bootload Mode	17
Settings for Alexa and OurWeather	18
Settings for WXLink / Solar WXLink	18
Setting up the OurWeather Twitter Interface	18
Setting up the OurWeather CWOP Interface	18
Setting up the OurWeather WeatherUnderground Interface	18

## Revisions

## Version 3.0 - January 2018 - Added Alexa to OurWeather Interface Information

## Using the REST Interface built into OurWeather

Set up your OurWeather system as shown in the OurWeather Assembly Manual.

## Testing the REST Interface

Now that you have OurWeather setup and working, it's time to test the first REST command.

Open a browser (Chrome, Safari, Internet Explorer or Edge - if your browser doesn't work, download and install Chrome) and type in the following (substitute your OurWeather IP address for 192.x.x.x):

http://192.168.1.118/FullDataString

returns:

```
{"FullDataString":
"22.08,30.01,27.68,103266.00,493.28,0.00,0.00,0.00,0.00,0.00,0.00,0.00,0.00,0.00,0.00,0,1969
-12-31 17:17:50,,752,4,0.00,0.00,0.00,0.00,0.00,0.00,0.00,0.00,0.00,0.00,0.00,0.00,V:,WXLMB ,
0,,,0,,", "id": "1", "name": "OurWeather", "hardware": "esp32", "Controllerboard": "V2",
"connected": true}
```

Which contains a bunch of weather information from the OurWeather station. Note: Your `FullDataString` will have more information in it if you are using software version 019 or later.

After doing that, you now have access to all of these REST commands.

The supported REST commands are:

## REST Variables

For example, to access the OurWeather REST variables type into a browser:

http://192.168.1.118/FullDataString

returns:

```
{"FullDataString":  
"21.30,36.70,25.63,101714.00,620.44,0.00,0.00,0.00,0.70,0.00,0.00,0.00,0.00,0.00,0.00,0.00,0.04/2  
4/2016 11:56:10,SwitchDoc Labs", "id": "1", "name": "OurWeather", "connected": true}
```

REST Variables		
Variable	Return	Example
OurWeatherTime	OurWeather Time and Date	<pre>{"OurWeatherTime": "05/21/2016 10:09:59", "id": "1", "name": "OurWeather", "connected": true}</pre>
FullDataString	String of Weather Data	See description of the FullDataString after this table
FirmwareVersion	Which software version is OurWeather running	<pre>{"FirmwareVersion" : "016", "id": "1", "name": "OurWeather", "connected": true}</pre>
IndoorTemperature	Temperature sensor on BMP280 on the WeatherPlus board. Always reports in degrees C.	<pre>{"IndoorTemperatur e": 27.47, "id": "1", "name": "OurWeather", "connected": true}</pre>
BarometricPressure	Barometric Pressure sensor on BMP280 on the WeatherPlus board. Always reports in Pascals.	<pre>{"BarometricPressu re": 100958.00, "id": "1", "name": "OurWeather", "connected": true}</pre>

REST Variables		
Altitude	Altitude calculated from BMP280. Always reports in meters.	<code>{"Altitude": 682.52, "id": "1", "name": "OurWeather", "connected": true}</code>
OutdoorTemperature	Outdoor Temperature from the AM2315. Always reports in degrees C.	<code>{"OutdoorTemperature": 23.60, "id": "1", "name": "OurWeather", "connected": true}</code>
OutdoorHumidity	Outdoor Relative Humidity from the AM2315. Always reports in % RH.	<code>{"OutdoorHumidity": 35.70, "id": "1", "name": "OurWeather", "connected": true}</code>
CurrentWindSpeed	Current Wind Speed from the WeatherRack - Always reports in kph (kilometer per hour).	<code>{"CurrentWindSpeed": 0.00, "id": "1", "name": "OurWeather", "connected": true}</code>
CurrentWindGust	Current Wind Speed from the WeatherRack - Always reports in kph (kilometer per hour).	<code>{"CurrentWindGust": 18.00, "id": "1", "name": "OurWeather", "connected": true}</code>

REST Variables		
CurrentWindDirection	Current Wind Direction from the WeatherRack - Always reports in degrees. 0 = due North.	{ "CurrentWindDirection": 90.00, "id": "1", "name": "OurWeather", "connected": true }
EnglishOrMetric	Is the Weather DISPLAY set to English or Metric units. 0 means English units, 1 means Metric units. The REST interface always sends Metric unit.	{ "EnglishOrMetric": 0, "id": "1", "name": "OurWeather", "connected": true }
RainTotal	Current Rain Total since last reboot of WeatherPlus. Always reports in mm.	{ "RainTotal": 0.28, "id": "1", "name": "OurWeather", "connected": true }
WindSpeedMin	Wind Speed Minimum as calculated by WeatherPlus over the past 50 seconds. Always reports in kph.	{ "WindSpeedMin": 0.00, "id": "1", "name": "OurWeather", "connected": true }
WindSpeedMax	Wind Speed Maximum as calculated by WeatherPlus over the past 50 seconds. Always reports in kph.	{ "WindSpeedMax": 2.50, "id": "1", "name": "OurWeather", "connected": true }

REST Variables		
WindGustMin	Wind Gust Minimum as calculated by WeatherPlus over the past 50 seconds. Always reports in kph.	<code>{"WindGustMin": 0.00, "id": "1", "name": "OurWeather", "connected": true}</code>
WindGustMax	Wind Gust Maximum as calculated by WeatherPlus over the past 50 seconds. Always reports in kph.	<code>{"WindGustMax": 6.50, "id": "1", "name": "OurWeather", "connected": true}</code>
WindDirectionMin	Wind Direction Minimum as calculated by WeatherPlus over the past 50 seconds. Always reports in degrees - 0 is due north.	<code>{"WindDirectionMin": 0.00, "id": "1", "name": "OurWeather", "connected": true}</code>
WindDirectionMax	Wind Direction Minimum as calculated by WeatherPlus over the past 50 seconds. Always reports in degrees - 0 is due north.	<code>{"WindDirectionMax": 275.00, "id": "1", "name": "OurWeather", "connected": true}</code>
AirQualitySensor	Instantaneous Air Quality. Reports a value from 0 (very clean) to ~32000 (very dirty). See the Our Weather Air Quality Extender Manual on <a href="http://www.switchdoc.com">www.switchdoc.com</a> on the store.	<code>{"AirQualitySensor": 1400, "id": "1", "name": "OurWeather", "connected": true}</code>



REST Variables		
ThunderBoardLast	Returns all the current lightning information from OurWeather	<pre>{ "ThunderBoardLast": "20 km, 03/31/2018 14:37:54, 20, Lightning detected, 03/31/2018 14:37:54, 1", "id": "1", "name": "OurWeather", "connected": true }</pre>
ThunderBoardParams	Returns the current ThunderBoard Parameters	<pre>{ "ThunderBoardParams": "2, 1, 7, 0, 2, 2", "id": "1", "name": "OurWeather", "connected": true }</pre>

Format of the specialized JSON for the ThunderBoardLast response:

as3935\_LastLightning - Distance of the last lightning strike (e.g. 7km)  
 as3935\_LastLightningTimeStamp - Time of the last lightning strike  
 as3935\_LastLightningDistance - integer distance (e.g. 7)  
 as3935\_LastEvent - The last event recorded by the ThunderBoard (see below)  
 as3935\_LastEventTimeStamp - Time Stamp of last event  
 as3835\_LightningCountSinceBootup - Number of lightning strikes since bootup

Format of the specialized JSON for the ThunderBoardParams response:

as3935\_NoiseFloor - Current Noise Floor (0-7)  
 as3935\_Indoor - Indoor (0) Outdoor (1)

as3935\_TuneCap - Current Tune Cap value for the AS3935 (0-15)  
as3935\_DisturberDetection - 0 - detect and report disturbers 1 - do not report  
as3935\_WatchdogThreshold - WatchDog Threshold (0-15)  
as3935\_SpikeDetection - Spike Rejection Value (0-15)

## Structure of the FullDataString Return Value

```
{"FullDataString":  
"21.30,36.70,25.63,101714.00,620.44,0.00,0.00,0.00,0.70,0.00,0.00,0.00,0.00,0.00,0.00,0.04/2  
4/2016 11:56:10,SwitchDoc Labs,  
0,4,3.62,35.20,2.78,0.00,4.96,25.20,0.00,0.00,0.00,0.00,0.00,0.00,V:0,WXLMB ,", "id": "1",  
"name": "OurWeather", "connected": true}
```

The values in the FullDataString are all in metric. See metric units in the above table.

- Outdoor Temperature
- Outdoor Humidity
- Indoor Temperature
- Barometric Pressure
- Altitude
- Current Wind Speed
- Current Wind Gust
- Current Wind Direction
- Rain Total
- Wind Speed Minimum
- Wind Speed Maximum
- Window Gust Minimum
- Window Gust Maximum
- Wind Direction Minimum
- Wind Direction Maximum
- Is Display English (1) Or Metric (0)
- Current Date/Time on OurWeather
- OurWeather Station Name
- Current Air Quality Sensor Reading
- Current Air Quality Qualitative Reading
- SunAirPlus Battery Voltage
- SunAirPlus Battery Current
- SunAirPlus Solar Panel Voltage
- SunAirPlus Solar Panel Current
- Load Voltage (into OurWeather)
- Load Current (into OurWeather)
- WXLink Battery Voltage
- WXLink Battery Current

- WXLINK Solar Panel Voltage
- WXLINK Solar Panel Current
- Always 0.00
- WXLINK Load Current
- WXLINK AM2315 Temperature Validation IVF: Means Invalid Temperature Found, V: Means Valid found
- WXLINK Message Status: WXLMSG - WXLINK Last Message Good, WXLMB - WXLINK Last Message Bad
- Alexa Enabled (1) or Not (0)
- as3935\_LastLightning - Distance of the last lightning strike (e.g. 7km)
- as3935\_LastLightningTimeStamp - Time of the last lightning strike
- as3935\_LastLightningDistance - integer distance (e.g. 7)
- as3935\_LastEvent - The last event recorded by the ThunderBoard (see below)
- as3935\_LastEventTimeStamp - Time Stamp of last event
- as3835\_LightningCountSinceBootup - Number of lightning strikes since bootup
- Controllerboard - Not present for V1, V2 for Version 2

Note: As more devices are added and supported by OurWeather, this string will continue to increase beyond these values, but only at the end of the string.

## REST Commands

REST Commands			
Variable	Function	Parameters	Returns
arduino	For ArduinoinConnect	Not Implemented	
	<b>External commands</b>		

REST Commands			
led	Controls red LED connected to GPIO0 on the WeatherPlus Board	<a href="http://192.168.1.118:/LED?params=1">http://192.168.1.118:/LED?params=1</a>  1 means on, 0 means off	<pre>{ "return_value": 1, "id": "1", "name": "OurWeather", "connected": true }</pre>
setID	sets the ID of the OurWeather at the IP address. Returned in "id" field	<a href="http://192.168.1.118/setID?params=2">http://192.168.1.118/setID?params=2</a>  Parameter is the new ID. Alphanumeric allowed	<pre>{ "return_value": 1, "id": "2", "name": "OurWeather", "connected": true } - Note new ID#</pre>
resetOurWeather	Restarts OurWeather to default. Works most of the time on the ESP8266.	<a href="http://192.168.1.118/resetOurWeather?params=adminpassword">http://192.168.1.118/resetOurWeather?params=adminpassword</a>  Parameter is administration password	return_value will be 1 if reset command was accepted, 0 if not (as in password failure)
setAdminPassword	reset Administration Password	<a href="http://192.168.1.118/setAdminPassword?params=oldpassword,newpassword">http://192.168.1.118/setAdminPassword?params=oldpassword,newpassword</a>  Parameters are old and new password, separated by a ","	return_value will be 1 if the command succeeded and 0 if it did not (such as invalid password)

REST Commands			
setDateTime	sets Data and Time on the DS321 Real Time Clock on WeatherPlus	<p>http://192.168.1.118/setDateTime?params=password,Jan 31 2016,14:03:00</p> <p>Admin password is first parameter. Note the exact non-tolerant format of the data time. Spaces are important.</p>	As of OurWeather software version 017, return_value will be 0 if password fails, 2 if the date or time is bad and 1 if the set date/time succeeds
resetToDefaults	reset Our Weather to default values	Not Implemented	Not Implemented
resetWiFiAccessPoint	resets OurWeather Access Point values to initial values. OurWeather will be at 192.168.1.4 and act as an access point. See OurWeather Assembly Manual to set up.	<p>http://192.168.1.118/resetWiFiAccessPoint?params=adminpassword</p> <p>Parameter is administration password</p>	return_value is 1 if it succeeds (and you will never receive it if it does) or 0 if the password fails.
updateOurWeather	Does an Over-The-Air (OTA) on OurWeather from the latest software located at <a href="http://www.switchdoc.com">www.switchdoc.com</a>	<p><a href="http://192.168.1.118/?params=adminpassword">http://192.168.1.118/?params=adminpassword</a></p> <p>Parameter is administration password</p>	return_value is 0 if the password fails, 1 if the update failed, 2 if there are no updates, 3 if it succeeds. You generally will not receive 3 as the ESP8266 will be rebooting.
	<b>External Interfaces</b>		
enableCWOP	Enables the CWOP interface for OurWeather	Not Implemented	Not Implemented

REST Commands			
enableTwitter	Enables the Twitter Interface for OurWeather	Not Implemented	Not Implemented
	<b>Weather Display Functions</b>		
WeatherSmall	Sets the OurWeather OLED display to small characters	<a href="http://192.168.1.118/WeatherSmall">http://192.168.1.118/WeatherSmall</a>	return_value is 1
WeatherMedium	Sets the OurWeather OLED display to medium characters	<a href="http://192.168.1.118/WeatherMedium">http://192.168.1.118/WeatherMedium</a>	return_value is 1
WeatherLarge	Sets the OurWeather OLED display to large characters	<a href="http://192.168.1.118/WeatherLarge">http://192.168.1.118/WeatherLarge</a>	return_value is 1

## REST Commands

WeatherDemo	Sets the OurWeather OLED display to Demo mode. Senses and moves fast showing values that people can quickly change like outside temperature/ humidity, wind speed, direction and rain. Used in classroom demonstrations where the instruments are located for people to change and turn.	<a href="http://192.168.1.118/WeatherDemo">http://192.168.1.118/WeatherDemo</a>	return_value is 1
EnglishUnits	Sets the OurWeather OLED display to show English Units	<a href="http://192.168.1.118/EnglishUnits">http://192.168.1.118/EnglishUnits</a>	return_value is 1
MetricUnits	Sets the OurWeather OLED display to show Metric	<a href="http://192.168.1.118/MetricUnits">http://192.168.1.118/MetricUnits</a>	return_value is 1

REST Commands			
EnablePubNub	Enable/disable PubNub (Alexa) on OurWeather - sets the Pub and Sub keys	<a href="http://192.168.1.102/EnablePubNub?params=admin,1,pub-cc4d6662-190a-42afa14d-3be4e6040ff6,sub-c-47725a16-f0e7-11e7-9869-a6bd95f83dd1">http://192.168.1.102/EnablePubNub?params=admin,1,pub-cc4d6662-190a-42afa14d-3be4e6040ff6,sub-c-47725a16-f0e7-11e7-9869-a6bd95f83dd1</a>  Admin password is first parameter. Second parameter is Enable (1) or Disable (0) Alexa. Third Parameter is the MQTT PubNub Publish Key and the Fourth Parameter is the MQTT PubNub Subscribe Key	As of OurWeather software version 026, return_value will be 0 if password fails, 1 if the set pub/sub key succeeds
SendPubNubState	Sends an MQTT Message to the PubNub site. Great to start things out.	<a href="http://192.168.1.102/SendPubNubState?params=admin">http://192.168.1.102/SendPubNubState?params=admin</a>  First Parameter is the Admin password	return value is 1
setThunderBoardParams		<a href="http://192.168.1.146/setThunderBoardParams?params=admin,2,1,7,0,2,2">http://192.168.1.146/setThunderBoardParams?params=admin,2,1,7,0,2,2</a>  The numbers after the password contain the parameters to be set. Some order as reported in the ThunderBoardParm variable above	return value 0 if fails password  return value of 1 if successful  return value of 2 means illegal parameter value

## How to Program Your OurWeather

Download the Arduino IDE 1.6.9 (or higher) to start from [arduino.cc](http://arduino.cc)



## Installation of the IDE

With the new 1.6.9+ releases of the Arduino IDE, it is much simpler to add and manage new boards. In the case of the Adafruit Huzzah ESP8266, it a simple process. Rather than repeat the tutorial here, we would suggest following the [Adafruit tutorial](#).

Use Version 1.6.9+ of the Arduino IDE for better results.

Download the software at <https://learn.adafruit.com/adafruit-huzzah-esp8266-breakout/using-arduino-ide>

Make sure you have selected Adafruit Huzzah as the board under the tools menu.

## Download the WeatherPlus Software for OurWeather

Move to where you wish to store your Arduino program and use the command line to clone the OurWeather/WeatherPlus software

git clone <https://github.com/switchdoclabs/OurWeatherWeatherPlus>

This will create a directory called SDL\_ESP8266\_WeatherPlus.

Now use the Arduino File menu to open the Compile and download the program to the WeatherPlus Board .

## To Set the WeatherPlus Board into Bootload Mode

- Hold down the **GPIO0** button, the red LED will be lit
- While holding down **GPIO0**, click the **RESET** button
- Release **RESET**, then release **GPIO0**
- When you release the RESET button, the red LED will be lit dimly, this means its ready to bootload

Then compile and load the software. Make sure you have selected the “Adafruit Huzzah” board under the tools menu.

## **Settings for Alexa and OurWeather**

See the Tutorial on [switchdoc.com](http://www.switchdoc.com)

<http://www.switchdoc.com/2018/01/tutorial-voice-time-ourweather-and-amazon-alexa-part-1/>

## **Settings for WXLink / Solar WXLink**

See the OurWeather Solar WXLink Manual

## **Setting up the OurWeather Twitter Interface**

Not Implemented as of OurWeather Software Version 050

## **Setting up the OurWeather CWOP Interface**

Not Implemented as of OurWeather Software Version 050

## **Setting up the OurWeather WeatherUnderground Interface**

See the OurWeather WeatherUnderground Manual